

Refurbishing Your Chain Link Fence:

To fasten the bamboo panel to the supports system follow the next set of instructions below:

The only tool required to install against a chain link is a nice set of pliers. You will also need to purchase some 14 or 16 gauge galvanized steel tie wire from your local hardware store.



This is really easy:

- 1) First straighten out any kinks or humps in your chain link fence in order to get a flat fence.
- 2) Attach your Cali Bamboo panels by simply rolling out the panel flush against the fence. Snip your tie wire into 6 inch pieces.
- 3) Slip the tie wire around the cane and twist it around the chain link until snug. Cut off the remains if you like. Do this at the top and bottom until the bamboo is secure. That's it!!

